


Mounting instruction

BannerUp BigPlus 120 / 4 ft. Silver with carrying bag, Item 81137

7,3 kg

Facts
Banner width
Full height w/ cassette
Visible banner height
Weight (excl. banner)
Cassette dimension

120 cm (47.25") 212 cm (83.5") 294 cm (115.75") (16 lbs) 14x11x121 cm (5.5" x 4.5" x 48")







Take out the BannerUp from the carrying bag.



Mounting instruction

For increased stability pull out the four support legs on the cassette.



Take two of the pole sections (start with the untapered) and mount these on each side of the cassette.



Pull the banner halfway out of the cassette.

Mark Bric Display Corp.



Hook the third pole section to the top rail of the banner. Push the banner up to full height to complete pole assembly.

Mounting Spotlight



Slide the spotlight along the top rail groove.



5



North America Tel. 800.742.6275 Fax 800.565.9506 E-mail: markbric@markbric.com Mark Bric Display AB Worldwide Headquarters Tel. +46 33 480 460 Fax +46 33 480 470 E-mail: display@markbric.se

4

Display



Production of printed banner

The banner material can be vinyl, fabric, double sided laminated paper etc. Laminated banner material should be soft (supple) enough to roll easily around the cassette roller at normal spring tension. 0,45 mm (0.018") is the maximum thickness to be used.


Banner dimensions Visible part of banner material: 2940 mm (115.75")

Printed length of banner: 2980 mm (117.32")

Min. extra banner material (unprinted): 40 mm (15")

Total length of banner material: 3280 mm (129.15")

Width, max (do not exceed): 1200 mm (47.25")




Mounting of top and bottom rail

Top rail

Mount the top rail on the reverse side of the banner, parallel to the upper edge.

Bottom rail



Maximum security

Carefully make holes in the

banner to align with the holes in the rail. Insert the

plastic push pins provided.

For extra security, mount a tape over the rail and banner.

Mounting of printed banner





Hold the banner and remove the locking pin.



Let the banner slowly roll into the cassette.

Change of printed banner



Roll the old banner out of the cassette.





Slide the banner out.

Application Techniques

To obtain optimum adhesion, the bonding surfaces must be well unified, clean and dry. Typical surface cleaning solvents are isopropyl alcohol/water mixture (rubbing alcohol) or heptane. Note: Be sure to follow solvent manufacturer's precautions and directions for use when using solvents. (Step A and B).

Bond strength is dependent upon the amount of adhesive-to-surface contact developed. Firm application pressure develops better adhesive contact and helps improve bond strength (Step C). After application, the bond strength will increase as the adhesive flows onto the surface. At room temperature approximately 50% of the ultimate strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours. In some cases bond strength can be achieved more quickly by exposure of the bond to elevated temperatures (e.g. 150°F /66°C) for 1 hour). This provides better adhesive onto the substrates.



Step A: Solvent wipe



Step C: Firm pressure onto surface







Mark Bric Display Corp. North America Tel. 800.742.6275 Fax 800.565.9506 E-mail: markbric@markbric.com

Mark Bric Display AB

Worldwide Headquarters Tel. +46 33 480 460 Fax +46 33 480 470 E-mail: display@markbric.se

